


ipega®

派鲨鱼

8合1 Joypad充电座

产品说明书(PG-SW2203)

产品外观图示



适用说明:

1. 本产品是一款配合NS 2原装底座使用的充电座，适用于NS / NS OLED与NS 2 Joypad手柄；
2. 配备8个充电插槽，支持给1至4个NS 一代Joypad手柄或NS 2 Joypad手柄同时充电；
3. 配备Type-C输入接口，支持NS/ NS 2原装底座为产品提供电源输入；
4. 配备RGB炫彩灯，共有9种可调节灯效；
5. 配备灯效触摸开关，可控制RGB灯在9种灯光效果中依次切换，长按3秒可关闭RGB灯效。
6. 配备充电指示灯，实时指示充电状态；
7. 配备充电触摸开关，可控制充电功能及充电指示灯的开启与关闭。

电性参数:

1. 输入电压: DC 5V
2. 单个手柄充电电流: 200mA
3. 充电时间: 2.5-3.5小时

设备使用说明:

1. 通过type-C充电线将产品接入NS 2/ NS原装底座，为产品提供电源输入。
2. 产品通电后，4个Joypad手柄充电指示灯蓝色常亮。
3. 将NS 1 Joypad手柄或NS 2 Joypad手柄插入对应的充电插槽进行充电，充电时对应指示灯橙色常亮，充满电对应指示灯蓝色常亮。
4. 充电功能控制：短按充电触摸开关可开启或关闭充电功能，充电功能关闭时充电指示灯同时熄灭。
5. RGB灯效调节：短按灯效触摸开关可控制RGB灯在9种灯光效果中依次循环切换，长按3秒保存当前灯效并熄灭，再次短按点亮之前保存的灯效。

产品注意事项:



NS官方Dock具有充电保护功能，当客户插拔主机或切换TV模式时会重启电源，导致产品的充电指示灯闪烁3-5次，此为正常现象，产品无问题，请放心使用。

1. 请不要把本产品在潮湿或高温地方存储。
2. 请不要敲击、摔打、刺穿、或试图去分解本产品，以免对产品造成不必要的损害。
3. 非专业人士勿拆卸本产品，否则不在售后保修服务内。
4. 请勿随意丢弃本产品，须给有资质的机构回收。
5. 因不可抗拒的因素造成部分产品无法连接操作，我公司不负任何责任，对此我公司保留最终解释权。
6. 请勿用于其他非NS/ NS 2原装Joypad手柄充电。

产品清单:



充电座x1



USB充电线x1



说明书x1




派答鱼

8 in 1 Charging Dock for NS/ NS 2 Joypad

Product Manual (PG-SW2203)

Product Appearance:



Applicable Instructions:

- 1.This product is a charging dock designed to be used with the original NS 2 dock, suitable for NS / NS OLED and NS 2 Joypad controllers.
- 2.Equipped with 8 charging slots, it supports simultaneous charging for one to four NS Joypad controllers or NS 2 Joypad controllers.
- 3.Features a Type-C input port, allowing the original NS / NS 2 dock to supply power.
- 4.Outfitted with RGB ambient lighting, offering 9 adjustable lighting effects.
- 5.Includes a touch switch for the light effects, allowing you to cycle through the 9 lighting modes with a short press. A long press for 3 seconds will turn off the RGB lights.
- 6.Features charging indicators to show the real-time charging status.
- 7.Equipped with a charging touch switch to control the on/off state of the charging function and its indicators.

Electrical Parameters:

- 1.Input Voltage: DC 5V
- 2.Single Charging Current: 200mA
3. Charging time: 2.5-3.5H

Instructions:


- 1.Connect the product to the original NS 2 dock and provide power input to the product through the charging cable.
- 2.After the product is powered on, the 4 Joypad charging indicators will light up blue.
- 3.Insert the Joypad into any slot for charging. The corresponding indicator light will be blue when fully charged.
- 4.Charging Function Control: A short press of the charging touch switch turns the charging function on or off. When charging is turned off, the charging indicators will also extinguish.
- 5.RGB Lighting Adjustment: A short press of the light effect touch switch cycles through the 9 RGB lighting effects. A long press for 3 seconds saves the current light effect and turns the lights off. Another short press will turn the lights back on to the previously saved effect.

Notes:



- 1.The official dock has a power protection feature that briefly resets power when switching TV mode or docking/undocking the console. This may cause connected devices to flash or restart. It's normal and not a product issue.
- 2.Non-professionals should not disassemble this product, otherwise, it will not be covered by the after-sales warranty service.
- 3.Please do not discard this product at will. It must be recycled by a qualified organization.
- 4.Our company is not responsible for some products that cannot be connected and operated due to irresistible factors. Our company reserves the final right of interpretation.
- 5.Do not use it for charging Joypad other than the original NS/ NS 2.

Product List:



Charging Dock x1

Charging Cable x1

Instructions x1